

# SkyBox S1

## Skype/landline USB Adapter

### Main Features

#### Flexibility

- Make both Skype™ and landline calls with an existing regular or cordless phone
- **After SkyBox S1 is integrated with existing PBX, employees can call Skype/SkypeOut™ via office desk phones**
- Support 20, 25, 30 and 50Hz ring frequency
- Support 2 REN standard loads
- Support standard windows USB audio device with a unique device ID
- **Support international busy tone to connect with most PBXs feasibly**
- SkyBox S1 is in the landline mode for an emergency call by default when PC is off



#### Mobility

- **With SkyBox S1, you can have a free mobile Skype call to office** (Support Skype chat to send office extension number, please refer to user manual FAQ 25.) **or home to save roaming or expensive mobile fees when you are out of office or home**
- Connect Skype through your phone, no need for microphone and speaker
- Support various cordless phones including DECT, 5.8GHz, 2.4GHz, 900 MHz or other phones

#### Simplicity

- **Similar telephone call behavior as a traditional landline call**
- Support Skype speed dial and SkypeOut directly through the phone keypad
- Support FSK type I caller ID for Skype calls and display speed dial number for easy returned call
- Easy of use and user-friendly interface
- LINE and PHONE RJ11 ports Auto-Detection and Auto-Swap when the device starts up



Normal Wiring



Wrong Wiring but Functional

#### Functionality

- **Skype speed dial export for backup and import for use**

- Support automatic assigned Skype/SkypeOut callout when the connecting phone is off-hook (DOD)
- Support assigned PBX extension number auto-dialing for incoming Skype calls during SkyBox S1's PBX application (DID)
- Switch between Skype and landline mode by pressing phone key “#”
- Switch between a landline call and a Skype call by pressing phone keys “\*1” and hang up current call by pressing phone key “\*”
- Add an interrupt Skype call or an interrupt landline call into a Skype & landline 3 way Conference by pressing phone keys “\*2”
- Support Skype or landline call waiting (Skype ↔ landline ) by pressing phone keys “\*1”
- Audio recovery button resolves Skype call party's problem to hear each other
- IM mode supports other IM/VOIP like Teams, Lync/Skype for business, Google talk/hangouts, WhatsApp, Zoom, LINE, ... as an audio device (Ear/Microphone function). When SkyBox S1 connects with office existing conference phones, the conference phones will become dedicated Skype conference phones. And the conference phones become IM conference phones when SkyBox S1 is set in IM mode
- Support SkyBox S1 software on-line upgrade or latest version check/download
- Option for phone line polarity reversal

## Application



## Minimum System Requirements

- One Computer with a free USB port, and 500MB free disk space
- Microsoft 64-bit Windows 7, 8, 10, or 11. Not support 32-bit version
- Support Skype 8.129.0.202
- Internet connection (WiFi, ADSL, Cable Modem, 4/5 G, ....., etc)

## Product Specification

- USB 1.1 standard
- Two RJ-11 ports. One PHONE(FXS) port is for standard analog or cordless phone sets (Or standard PBX analog trunk line); the other LINE(FXO) port is for traditional landline
- USB bus power (No external power needed)

- Dimensions (LxWXH): 95 X 66 X 22 mm

**SkyBox S1 introduction YouTube:** <https://www.youtube.com/watch?v=bNaTskJVTR4>

*(You can enable YouTube caption setting.)*



**Regintech web:** <https://www.regintech.com.tw>

